

For your own Safety

Warning signs



Danger High Risk!

Ignoring this warning can be life threatening and can cause damage to the body.



Attention Medium Risk!

Ignoring this warning can cause property damage.



Caution Low Risk!

The careful handling of problems is required, which can occur while handling the device.

Important Advice

Danger Flammable!



The glowing charcoal and the operating grill parts can get very hot and can ignite fires.

- A fire extinguisher and a first aid kit should be to hand at all times in case of an accident or fire.
- Place grill on a flat, horizontal, safe, heat-resistant and clean surface.
- Place the grill so, that it is at least 1 m away from highly-inflammable materials, such as Awnings, wooden decks or furniture.
- While in operation do not transport the product
- Only burn the coal in the sheltered area.
- Fill the BBQ with maximum 3 kg of charcoal
- Some foods produce combustible fats and juices. Therefore the BBQ needs to be cleaned regularly, preferably after each use.
- Dispose of the ashes only when the charcoal is completely burned out and cooled down.



Danger Combustion and Accidents!

This appliance should not be used by a person (including children) with reduced physical, sensory or lack of experience / knowledge. Therefore people with these conditions should be made aware of the dangers of the product and should be supervised by another person for their own safety.

- Any changes to the product are a huge danger to your own safety and are forbidden. Therefore impermissible interventions should be prevented. If any damage, reparations or problems occur with the product, please contact our service desk or one of our present specialists.
- Children and Animals need to be kept away from the product at all times

The BBQ, the charcoal inside of the BBQ and the BBQ food become very hot while the BBQ is in use, so that any contact with them can lead to severe burns.

- Therefore please keep enough distance from the hot parts.
- Use kitchen gloves if you handle the BBQ at all times.
- Only use BBQ equipment with long heat protected handles.
- Do not wear clothes with loose sleeves.
- Only use dry lighter or special liquid barbecue lighter to light (please use the EN 1860-3 instructions).
- Please cool down the BBQ completely before you clean it or put it away.

Danger of Toxication!

Burning of Charcoal produces carbon monoxide – it has no scent and can lead to death if used in confined spaces
- As a result the BBQ should only be used outdoors.

Danger of Explosion!



Flammable Liquids which are poured into the fire can cause random flames or explosions.

- Never use flammable liquids like petrol and spirits.
- Do not soak the charcoal in flammable liquids or place the soaked charcoal in the flames.

Danger for Children!



Children can entangle themselves within the package foil while playing with it and can suffocate.

- Therefore children should not play with the package foil.
- Pay attention that your children will not put any of the applications parts in their mouth. They could swallow these and could choke as a result.

Risk of injury

On the BBQ and on the some of the features are sharp corners.

- The single features of the BBQ should be handled carefully, to prevent accidents or injury during the installation or during the general use of the BBQ. It may be advisable to wear protective gloves.
- Do not place the BBQ near Entrances or Exits or busy zones.
- Always handle the BBQ carefully while you barbecue. Any disturbances can lead to improper handling of the BBQ.

Always pay attention and take care of what you do with the BBQ. Do not use the BBQ if you are tired, not concentrating or under influence of drugs, alcohol or medicines. Failure to pay proper attention even for a short period of time while using the BBQ can lead to serious injuries.

Caution damage danger!



During the use of the BBQ it is possible that the screw starts to loosen and this can affect the stability of the BBQ.

- Therefore please check the screws before using the BBQ. If necessary please tighten the screws again to ensure stability.

Attention damage danger!



Do not use strong or grinding solvent or scouring pads, because they can damage the surface and leave abrasive marks