








1104A



2 If the cooking plate is unstable on the body, pls make it stable by adjusting the nut under the cooking plate.

